Safety belts should stay on the strong, bony parts of the body. Shoulder belts must never be placed behind the back or under the arm.

